

设备安装使用说明书

► Equipment installation manual



智能商用收银一体机


Intelligent commercial cash register machine

1: 收银机安装步骤

Cash register installation steps



1.1: 取出设备及电源
1.1: Take out the device and power supply



1.2: 安装电源适配器
1.2: Install the power adaptor



1.3: 机身底部插入电源线
1.3: Plug in the power



1.4: 取出钱箱配件
1.4: Cash box accessories




1.5: 钱箱线插入对应接口
1.5: Cash box line interface




1.6: 打开装纸盖开关
1.6: Open the paper cover switch



1.7: 如图装入打印纸
1.7: Load paper as shown




1.8: 盖上装纸盖
1.8: Cover the paper cover



1.9: 点按机身右侧电源键开机
1.9: Press the power button to boot

2: 标签机安装步骤

Label machine installation steps




2.1: 取出设备及配件
2.1: Take out the equipment and accessories




2.2: 按下开盖键开关
2.2: Press the open cover switch



2.3: 装入标签纸
2.3: Load the label paper




2.4: 插入电源及USB线
2.4: Plug in the power and USB cables



2.5: 按电源键 开机
2.5: Press the power button to boot

3: 厨房打印机安装步骤


Kitchen printer installation steps



4.1: 取出设备及配件
4.1: Take out the equipment and accessories




4.2: 按下开盖键开关
4.2: Press the open cover switch



4.3: 装纸方式
4.3: Load the label paper



4.4: 插入电源及网线
4.4: Plug in the power and network cable



4.5: 按电源键 开机
4.5: Press the power button to boot




4.6: 网线接路由器
4.6: Network cable to the router

5:设备接口介绍

Device interface introduction

根据外接设备插上主机上对应的接口
主机接口扩展如下图



5:开箱检查

open box to check

1: 收银机开箱检查设备

打开收银机包装箱, 对照装箱单检查物品是否缺少或者损坏, 如果出现物品缺少或损坏的现象, 请联系代理商或客服中心. 拆箱后请保留好原包装 请勿丢弃。

2: 安装前准备

检查机身外壳是否完整无损坏, 配件是否齐全。

工作环境准备: 由于收银机设备属于精密设备, 使用前应检查周围工作环境是否符合收银机设备技术指标, 如有不符合请勿在该工作环境使用。

主要技术指标

电源	输入	12V $\pm$, 5A
环境要求	工作环境	0℃~40℃
	贮存环境	-15℃~50℃